

GENERAL DESCRIPTION The transmitter DAT2105 2W is able to execute several functions such as : measure and linearisation of the temperature characteristic of RTDs sensors, conversion of a linear resistance variation, conversion of a voltage signal even coming from a potentiometer connected on its input. The measured values are transmitted, in function of the configuration, on the 4+20 mA output loop.

The device guarantees high accuracy and performances stability both in time and in temperature.

The configuration of the device must be made with device not powered using the proper cable connected to the Micro-USB plug located on the front side The configuration of the device must be made by a Personal Computer using the software DATAPRO, developed by DATEXEL, that runs under the operative system "Windows™". For Resistance and RTDs sensors it is possible to set the cable compensation with 3 wires.

It is possible to set the minimum and maximum values of input and output ranges in any point of the scale, keeping the minimum span shown in the table below. Moreover it is available the option of alarm for signal interruption (burn-out) that allows to set the output value as high or low out of scale.

For the device it is foreseen the damping function that allows to set a programmable filter up to 30 seconds to reduce eventual fast variations on the input signal. In phase of order it is available the option "-POT"; if requested with this option the device will be equipped with potentiometers located on the front side that can be used to adjust the output signal in case on field it would be requested an handmade adjustment of the signal itself.

It is housed in a plastic enclosure of 12.5 mm thickness suitable for DIN rail mounting in compliance with EN-50022 and EN-50035 standards.

### **USER INSTRUCTIONS**

The 4+20 mA output signal is measurable in the power loop as shown in the section "Output/Power supply connection".

The input connections must be made as shown in the section "Input connection".

To configure the transmitter refer to section "Configuration".

# TECHNICAL SPECIFICATIONS (Typical at 25 °C and in nominal conditions)

Input type	Min	Max	Min. span	OUTPUT				POWER SUPPLY		
Voltage mV	-100 mV	+90 mV	5 mV	Туре	Min	Мах	Min Span	Reverse polarity protection 60 Vdc max		
mV mV	-100 mV -100 mV	+200 mV +800 mV	10 mV 20 mV	Current	4 mA	20 mA	4 mA	Load characterist	i <b>c - Rload</b> (maximum load p per power supply value)	
RTD(*) 2,3 wires   Pt100   Pt1000   Ni100   Ni1000   Pot.   (nom. Res < 50KΩ)	-200°C -85°C -60°C -60°C	850°C 185°C 180°C 150°C 100 %	50°C 30°C 50°C 30°C 10 %	Output calibration Current Burn-out values Max. output value Min. output value	n	± 7 21. 2.	7 uA .7 mA .2 mA	Ohm		
RES. 2,3 wires	0Ω 0Ω	500 Ω 2000 Ω	50 Ω 50 Ω	Potentiometer Adjustment (Option "- POT") 7 18 24 32 V			18 24 32 V			
Input calibration ( RTD Low RES High RES mV Potentiometer Linearity (1)	1) > of $\pm 0.1\%$ f.s. or $\pm 0.2^{\circ}$ C > of $\pm 0.1\%$ f.s. or $\pm 0.15 \Omega$ > of $\pm 0.2\%$ f.s. or $\pm 1 \Omega$ > of $\pm 0.1\%$ f.s. or $\pm 12 \text{ uV}$ $\pm 0.05 \%$ f.s			Zero Span			±5% ±5%	ENVIRONMENTAL CONDITIONSOperative Temperature-20°C +70°CStorage Temperature-40°C +85°CHumidity (not condensed)0 90 %Maximum Altitude2000 mInstallationIndoorCategory of installationIIPollution Degree2		
Input impedance mV Sensor excitation RTD,Res	± 0.1 % 1. >= 10 MΩ current 400 uA	2						MECHANICAL SPEC Material IP Code Wiring Tightening Torque Mounting	CIFICATIONS Self-extinguish plastic IP20 wires with diameter 0.8÷2.1 mm <sup>2</sup> /AWG 14-18 0.8 N m in compliance with DIN	
Line resistance influence (1) mV <=0.8 uV/Ohm PTD 3 wires 0.05% (0.500 may belanced)							Weight	rail standard EN-50022 and EN-50035 about 90 g.		
Thermal drift (1) ± 0.01% / °C			(1) referred to input Span (difference between max. and min. values)			and min. values)	<b>EMC ( for industrial</b> Immunity Emission	environments) EN 61000-6-2 EN 61000-6-4		

(\*) For temperature sensors it is possible to set the input range also in F degrees; to made the conversion use the formula: °F = (°C\*9/5)+32)

## CONFIGURATION

Notice: before to execute the next operations, check that the drivers of the cable CVPROG in use have been previously installed in the Personal Computer.

- 1) Open the plastic label protection on front side of the device.
- 2) Connect the two plugs of cable CVPROG to the Personal Computer
- (USB plug) and to the device (Micro-USB plug)
- 3) Run the software DATAPRO or later versions. Open the COM port assigned by Windows to the cable CVPROG.

PROGRAMMING

micro USB

CVPROG cable

USB

- 4) Select the device and set the parameters of configuration .
- 5) Program the device.

DAT

## INSTALLATION INSTRUCTIONS

The device is suitable for DIN rail mounting in vertical position. It is necessary to install the device in a place without vibrations; avoid to routing conductors near power signal cables.

# <u>WIRING</u>

## INPUT CONNECTION



## **OUTPUT / POWER SUPPLY CONNECTION**







R

#### HOW TO ORDER

The device is provided as requested on the Customer's order. In case of the configuration is not specified, the parameters must be set by the user. Refer to the section "Technical specification" to determine input and output ranges.

## ORDER CODE EXAMPLE:

DAT2105 2W / Pt100 / 3 wires / 0 ÷ 200 °C / 4 ÷ 20 mA / High / - POT

Input type	Ontion Potentiometers
ensor options : TD/RES:2,3 wires	for output adjustment
Input range	
Output range	
High or low Out of scale	J

The symbol reported on the product indicates that the product itself must not be considered as a domestic waste. It must be brought to the authorized recycle plant for the recycling of electrical and

Ó

electronic waste. For more information contact the proper office in the user's city , the service for the waste treatment or the supplier from which the product has been purchased.